















**TYPE:****MODEL:** Series II, IIA, III**YEAR:** 1958 - 1984**DETAIL:** LWB Pickup & Station Wagon,  
Snatana 109,  
SWB Santana 88

FRONT		QTY	PART NUMBER	PRICE	REAR		QTY	PART NUMBER	PRICE
<b>LEAF SPRING</b>									
	9 Leaves	1	LAND-9L-F RH			11 Leaves	1	LAND-SWB-R RH	
	Raised Height (40mm Lift)	1	LAND-9L-F LH			Raised Height (45mm Lift)	1	LAND-SWB-R LH	
<b>SHACKLE BUSH KIT</b>									
<b>SWB Series II, IIA, III</b>									
<b>LWB Series II, IIA</b>									
	Kit Contains: 4 x SPF2154 2 x SPF2212	1	PB51-1029K			8 Leaves	1	LAND-8L-R RH	
						Raised Height (45mm Lift)	1	LAND-8L-R LH	
<b>1973 on, Series III, LWB only</b>									
	Kit Contains: 4 x SPF2154 2 x SPF2155	1	PB51-1081K			6 x SPF2154	1	PB51-1030K	
<b>U-BOLT KIT</b>									
<b>Series II, IA</b>									
	Kit Contains: RHS - 1 x UB51-601-1 1 x UB51-901	1	UB51-901K			Kit Contains: 2 x UB51-601-1	2	UB51-601-1K	
	LHS - 2 x UB51-601-1	1	UB51-601-1K			Kit Contains: 2 x UB51-904	2	UB51-904K	
<b>Series III</b>									
	Kit Contains: RHS - 2 x UB51-903	1	UB51-903K						
	LHS - 1 x UB51-902 1 x UB51-903	1	UB51-902K						
<b>SHOCK ABSORBER</b>									
	Heavy Duty Twin Tube Gas	2	GS51-090			Heavy Duty Twin Tube Gas	2	GS21-015C	
<b>SHOCK ABSORBER</b>									
<b>Suits SWB, (LWB pre 1958)</b>									
<b>Suits LWB (1958 on)</b>									
	Heavy Duty Twin Tube Gas	2	GS59-631						
<b>STEERING DAMPER</b>									
	Heavy Duty (Big Bore) Complete with Fittings	1	SD51-811						