

4X4

MAKE: NISSAN

TYPE: Patrol

MODEL: Y60 GQ

YEAR: 02/1988 - 1998

DETAIL: SWB GR, Safari, KYY60



NISS-56

FRONT		QTY	PART NUMBER
<p><b>COIL SPRING</b></p> <p>Linear Rate Standard Height</p> <p>Linear Rate Raised Height (45mm Lift)</p> <p>Variable Rate Raised Height (45mm Lift)</p> <p>Variable Rate Raised Height (50mm Lift)</p> <p>50-100Kg Constant Load</p>	1	<b>C45-092</b> (B)	Price Code (if applicable) ↘
	1	<b>C45-094</b> (B)	
	1	<b>C45-096V</b> (B)	
	1	<b>C45-110V</b> (B)	
	.....		
<p><b>SHOCK ABSORBER</b></p> <p>Heavy Duty Twin Tube Gas</p> <p>Heavy Duty Monotube Remote Reservoir</p>	2	<b>GS45-114</b>	
	2	<b>MR45-60114</b>	
<p><b>STEERING DAMPER</b></p> <p>1988 - 08/1989 Heavy Duty (Big Bore) Complete with Fittings</p> <p>08/1989 - 1999 Heavy Duty (Big Bore) Complete with Fittings</p>	1	<b>SD45-834</b>	
	1	<b>SD45-836</b>	
<p><b>UNDER BODY BUSH KIT</b></p> <p>See Rear Under Body Bush Kit</p>	.....		
	<p><b>CASTOR ADJUSTMENT PARTS</b></p> <p><b>Adjustable</b> Front Radius Arm Castor Kit                  Angle Settings: <math>\pm 0^\circ</math>, <math>\pm 2.5^\circ</math> or <math>\pm 3.5^\circ</math>                  4 x Polyurethane Eccentric Bushes</p> <p>1 <b>PB59-503K</b></p> <p><b>Fixed Rubber</b> Front Radius Arm Castor Kit                  Angle Setting: <math>\pm 2.5^\circ</math>                  4 x Rubber Eccentric Bushes</p> <p>1 <b>RB59-522K</b></p>		
<p>Raising vehicle will effect castor angle.                  A wheel alignment is recommended to determine if a castor kit is required.</p>			
<p><b>SWAYBAR EXTENSIONS</b></p> <p><b>Adjustable</b> Swaybar Extension (Suits 2" - 6" Lift)</p>	2	<b>SE45-520</b>	
<p><b>GEARBOX SPACER KIT</b></p>	1	<b>TC45-001K</b>	
<p>Drive line vibration may occur with raised suspension. To reduce vibration we recommend fitting the above kit.</p>			

REAR		QTY	PART NUMBER
<p><b>COIL SPRING</b></p> <p>Linear Rate Standard Height</p> <p>Linear Rate Raised Height (45mm Lift)</p> <p>Variable Rate Raised Height (45mm Lift)</p> <p>Linear Rate Raised Height (50mm Lift)</p> <p>100-200Kg Constant Load</p>	1	<b>C45-093</b> (B)	Price Code (if applicable) ↘
	1	<b>C45-095</b> (B)	
	1	<b>C45-101V</b> (B)	
	1	<b>C45-189</b> (B)	
	.....		
<p><b>SHOCK ABSORBER</b></p> <p>Heavy Duty Twin Tube Gas</p> <p>Heavy Duty Monotube Remote Reservoir</p>	2	<b>GS45-115</b>	
	2	<b>MR45-60115</b>	
<p><b>UNDER BODY BUSH KIT</b></p> <p>Kit Includes Front &amp; Rear Under Body Bushes                  *Excludes Spherical Panhard Rod Bush for Models 02/2000 On (Wagon)</p>	.....		
	<p><b>Pre 1989</b></p> <p>4 x Front Radius Arm to Chassis Bush                  4 x Front Radius Arm to Diff Bush                  2 x Front Panhard Rod Bush                  2 x Rear Panhard Rod Bush                  8 x Rear Trailing Arm Bush</p> <p>1 <b>PB45-1231K</b></p>		
<p><b>1989 on</b></p> <p>4 x Front Radius Arm to Chassis Bush                  4 x Front Radius Arm to Diff Bush                  4 x Front &amp; Rear Panhard Rod Bush                  8 x Rear Upper &amp; Lower Trailing Arm Bush</p> <p>1 <b>PB45-1239K</b></p>			
<p><b>ALIGNMENT PARTS</b></p> <p>* Check Swaybar Link Configuration - Some vehicles require 2 of the same and others require 1 of each</p>			
<p><b>Adjustable</b> Swaybar Extension (Suits 2" - 6" Lift) Stem Upper / Right Angle Lower Joint</p>	1*	<b>SE45-520</b>	
<p><b>Adjustable</b> Swaybar Extension (Suits 2" - 6" Lift) Right Angle Upper / Right Angle Lower Joint</p>	1*	<b>SE45-521</b>	
<p><b>BRAKE ADJUSTER</b></p> <p>Recommended when raising vehicle (Suits 2" - 6" Lift)</p>			
	1	<b>BA45-005</b>	