




















TYPE: Sierra, Drover QB

MODEL: SJ410, SJ413, SJ50, SJ51, LJ410, LJ413

YEAR: 1981 on

DETAIL: Santana, Samurai, Rhino, Jimny
Different Front U-Bolts on 410 Model



FRONT		QTY	PART NUMBER	PRICE	REAR		QTY	PART NUMBER	PRICE
LEAF SPRING					LEAF SPRING				
Petrol									
	5 Leaves Raised Height (40mm Lift) 0-50Kg Accessories Fit in Pairs	2	SUZ-5L-F			4+1 Leaves Raised Height (40mm Lift) 0-100Kg Accessories Fit in Pairs	1	SUZ-4+1-R RH	
							1	SUZ-4+1-R LH	
Diesel									
	6 Leaves Raised Height (40mm Lift) 0-50kg Accessories Fit in Pairs	2	SUZ-6L-F		SHACKLE BUSH KIT				
						Kit Contains: 2 x PB57-1534 8 x PB57-1535	1	PB57-1034K	
SHACKLE BUSH KIT					U-BOLT KIT				
	Kit Contains: 2 x PB57-1534 8 x PB57-1535	1	PB57-1034K		SJ410, SJ413, SJ50, SJ51 Models				
						Kit Contains: 2 x UB57-655	2	UB57-655K	
U-BOLT KIT					SHOCK ABSORBER				
	Kit Contains:					Heavy Duty Twin Tube Gas	2	GS57-086	
SJ410 Models									
	Right Hand Side	2 x UB57-655	1	UB57-655K	SHACKLE				
	Left Hand Side	2 x UB29-900	1	UB29-900K		Fit in Pairs	2	SK57-041	
SJ413, SJ50, SJ51 Models (1985 - 1996)									
	Right Hand Side	2 x UB57-654	1	UB57-654K	PIN				
	Left Hand Side	2 x UB57-655	1	UB57-655K		Fit in Pairs	2	SP57-042	
SHOCK ABSORBER									
	Heavy Duty Twin Tube Gas	2	GS57-085		STEERING DAMPER				
STEERING DAMPER									
	Heavy Duty Complete with Fittings	1	SD57-030		SHACKLE				
SHACKLE									
	Fit in Pairs	2	SK57-041		PIN				
PIN									
	Fit in Pairs	2	SP57-042						