

MAKE: SUZUKI
 HOLDEN
MODEL: SJ, LJ 410/413
 SJ40, SJ50, SJ51, SJ70
DETAIL: Santana, Samurai, Rhino, Jimny
 Different U-Bolts on 410 Model

TYPE: Sierra
 Drover QB
YEAR: 1981 on



SUZ-51

SUZUKI

FRONT		QTY	PART NUMBER
<p>LEAF SPRING Single Stage</p>			Price Code (if applicable) ↘
Suits: Petrol	5 Leaves Raised Height (40mm Lift) No Accessories. Fit in Pairs	2	SUZ-5L-F
Suits: Diesel	6 Leaves Raised Height (40mm Lift) No Accessories. Fit in Pairs	2	SUZ-6L-F
<p>SHACKLE BUSH KIT</p>			
	Kit Contains: 2 x SPF176 8 x SPF173	1	PB57-1034K
<p>U-BOLT KIT</p>			
Suits: SJ410	Kit Contains: Right Hand Side 2 x UB57-655 Left Hand Side 2 x UB29-900	1	UB57-655K UB29-900K
Suits: SJ413, SJ50, SJ51 (1985 - 1996)	Right Hand Side 2 x UB57-654 Left Hand Side 2 x UB57-655	1	UB57-654K UB57-655K
<p>SHOCK ABSORBER</p>			
	Heavy Duty Twin Tube Gas	2	GS57-085
<p>STEERING DAMPER</p>			
	Heavy Duty Complete with Fittings	1	SD57-030
<p>SHACKLE KIT</p>			
	Fit in Pairs	2	SK57-041
<p>PIN KIT</p>			
	Fit in Pairs	2	SP57-042

REAR		QTY	PART NUMBER
<p>LEAF SPRING Two Stage</p>			Price Code (if applicable) ↘
	4+1 Leaves Raised Height (40mm Lift) No Accessories. Fit in Pairs	1	SUZ-4+1-R RH SUZ-4+1-R LH
<p>SHACKLE BUSH KIT</p>			
	Kit Contains: 2 x SPF176 8 x SPF173	1	PB57-1034K
<p>U-BOLT KIT</p>			
Suits: SJ410, SJ413, SJ50, SJ51	Kit Contains: 2 x UB57-655	2	UB57-655K
<p>SHOCK ABSORBER</p>			
	Heavy Duty Twin Tube Gas	2	GS57-086
<p>SHACKLE KIT</p>			
	Fit in Pairs	2	SK57-041
<p>PIN KIT</p>			
	Fit in Pairs	2	SP57-042