


















**TYPE:** Landcruiser 76 Series  
**MODEL:** FZJ76, HZJ76, VDJ76  
**YEAR:** 04/2007 on  
**DETAIL:** Station Wagon, V8 Turbo Diesel



FRONT		QTY	PART NUMBER	PRICE	REAR		QTY	PART NUMBER	PRICE
<b>COIL SPRING</b>					<b>LEAF SPRING</b>				
	Variable Rate Standard Height	1	<b>C59-454V</b>	B		4+2 Leaves Raised Height (45mm Lift) Medium Duty Up to 100Kg Constant Load	2	<b>L59-020-R</b>	
	Linear Rate Raised Height (40mm Lift) Comfort Option No Accessories	1	<b>C59-246</b>	B		5+2 Leaves Raised Height (50mm Lift) Heavy Duty 300Kg Constant Load	2	<b>L59-021-R</b>	
	Linear Rate Raised Height (40mm Lift)	1	<b>C59-250</b>	B		6+2 Leaves Raised Height (50mm Lift) Super Heavy Duty 450Kg Constant Load	2	<b>L59-022-R</b>	
	Linear Rate Raised Height (55mm Lift) Up to 80Kg Accessories (Bullbar OR Winch)	1	<b>C59-248</b>	B					
	Linear Rate Raised Height (50mm Lift) Super Heavy Duty 80-110Kg Accessories (Bullbar AND Winch)	1	<b>C59-252</b>	B	<b>SHACKLE BUSH KIT</b>				
<b>SHOCK ABSORBER</b>									
	Heavy Duty Twin Tube Gas	2	<b>GS45-114</b>		Kit Contains: 4 x SPF1781 2 x SPF1782 4 x SPF1798				
	Heavy Duty Monotube Remote Reservoir	2	<b>MR45-60114</b>		1 <b>PB59-1090K</b>				
<b>STEERING DAMPER</b>					<b>U-BOLT KIT</b>				
	Heavy Duty (Big Bore) Complete with Fittings	1	<b>SD59-825</b>		Kit Contains:				
						<b>L59-020-R</b>	2 x UB59-453-3	2	<b>UB59-453-3K</b>
<b>ADJUSTABLE PANHARD ROD</b>						<b>L59-021-R</b>	2 x UB59-453-3	2	<b>UB59-453-1K</b>
	Right Hand Drive Complete with Bushes	1	<b>PR59-1418</b>			<b>L59-022-R</b>	2 x UB59-453-1	2	<b>UB59-453-1K</b>
					<b>SHOCK ABSORBER</b>				
<b>UNDER BODY BUSH KIT</b>									
Kit Includes Front & Rear Under Body Bushes					Soft Option Twin Tube Gas (Big Bore)				
	2 x Front Panhard Rod Bush					Heavy Duty Twin Tube Gas (Big Bore)	2	<b>GS45-115</b>	
	2 x Front Leading Arm to Diff Bush					Heavy Duty Twin Tube Gas Long Travel (Big Bore)	2	<b>GS59-079</b>	
	4 x Front Leading Arm to Chassis Bush	1	<b>PB59-1261K</b>			Heavy Duty Monotube Remote Reservoir	2	<b>GS59-703</b>	
<b>RADIUS ARM BUSH</b>					<b>SHACKLE</b>				
	0 Degree Standard Radius Arm Bush Kit Arm to Diff	1	<b>RB59-536K</b>			Greasable: Fit in Pairs	2	<b>SK59-051</b>	
	4 x Rubber Bushes				<b>PIN</b>				
	Arm to Chassis Bush Kit	1	<b>RB59-534K</b>			Greasable: Fit in Pairs	2	<b>SP59-044</b>	
	2 x Rubber Bushes				<b>CASTOR ADJUSTMENT PART</b>				
	Adjustable Front Radius Arm Castor Kit Angle Settings: ±0° or ±2.5°	1	<b>PB59-503K</b>		Raising Vehicle Will Effect Castor Angle. A Wheel Alignment is Recommended to Determine if a Castor Kit is Required.				
	4 x Polyurethane Eccentric Bushes				<b>SWAYBAR EXTENSION</b>				
	Fixed Rubber Front Radius Arm Castor Kit Angle Setting: ±2.5°	1	<b>RB59-522K</b>		Adjustable Swaybar Extension (Suits 2" - 4" Lift)				
	4 x Rubber Eccentric Bushes				Must Be Fitted for Tail-Shaft/Swaybar Clearance				
<b>SWAYBAR EXTENSION</b>					<b>ABS CABLE BRACKET KIT</b>				
	Adjustable Swaybar Extension (Suits 2" - 4" Lift)	1	<b>WA59-543K</b>		ABS Cable Bracket Kit				
<b>ABS CABLE BRACKET KIT</b>					Must Be Fitted To Vehicles With ABS Brakes				
<b>COIL SPACER</b>					<b>COIL SPACER</b>				
	10mm	2	<b>PS21-4008</b>						
	30mm	2	<b>PS21-4009</b>						