

























TYPE: Landcruiser  
 MODEL: 76 Series - FZJ76, HZJ76, VDJ76  
 YEAR: 04/2007 on  
 DETAIL: Station Wagon, V8 Turbo Diesel









FRONT		QTY	PART NUMBER	PRICE	REAR		QTY	PART NUMBER	PRICE
<b>COIL SPRING</b>									
	Variable Rate Standard Height	1	<b>C59-454V</b>	B		4 + 2 Leaves Raised Height (45mm Lift) Medium Duty Up to 100Kg Constant Load	2	<b>L59-020-R</b>	
	Linear Rate Raised Height (40mm Lift) Comfort Option No Accessories	1	<b>C59-246</b>	B		5 + 2 Leaves Raised Height (50mm Lift) Heavy Duty 300Kg Constant Load	2	<b>L59-021-R</b>	
	Linear Rate Raised Height (40mm Lift)	1	<b>C59-250</b>	B		6 + 2 Leaves Raised Height (50mm Lift) Super Heavy Duty 450Kg Constant Load	2	<b>L59-022-R</b>	
	Linear Rate Raised Height (55mm Lift) Up to 80Kg Accessories (Bullbar OR Winch)	1	<b>C59-248</b>	B					
	Linear Rate Raised Height (50mm Lift) Super Heavy Duty 80-110Kg Accessories (Bullbar AND Winch)	1	<b>C59-252</b>	B					
<b>SHOCK ABSORBER</b>									
	Twin Tube Gas Heavy Duty	2	<b>GS45-114</b>						
	Monotube Remote Reservoir Heavy Duty	2	<b>MR45-60114</b>						
<b>SHOCK ABSORBER BRACKET</b>									
	Recommended For Optimal Remote Reservoir Positioning And Fitment	1	<b>RM59-006</b>						
Only For Use With MR45-60114									
<b>STEERING DAMPER</b>									
	Heavy Duty (Big Bore) Complete with Fittings	1	<b>SD59-825</b>						
<b>ADJUSTABLE PANHARD ROD</b>									
	Right Hand Drive Complete with Bushes	1	<b>PR59-1418</b>						
<b>UNDER BODY BUSH KIT</b>									
Kit Includes Front & Rear Under Body Bushes									
	Kit Contains: 2 x Front Panhard Rod Bush 2 x Front Leading Arm to Diff Bush 4 x Front Leading Arm to Chassis Bush	1	<b>PB59-1261K</b>						
<b>RADIUS ARM BUSH</b>									
	0 Degree Standard Radius Arm Bush Kit Arm to Diff 4 x Rubber Bushes	1	<b>RB59-536K</b>						
	Arm to Chassis Bush Kit 2 x Rubber Bushes	1	<b>RB59-534K</b>						
<b>CONTINUED ON NEXT PAGE</b>									
<b>SHACKLE BUSH KIT</b>									
	Kit Contains: 4 x PB59-1536 2 x PB59-1538 4 x PB59-1537	1	<b>PB59-1090K</b>						
<b>U-BOLT KIT</b>									
	Suits <b>L59-020-R</b> Kit Contains: 2 x UB59-453-3	2	<b>UB59-453-3K</b>			Suits <b>L59-021-R</b> Kit Contains: 2 x UB59-453-3	2	<b>UB59-453-1K</b>	
	Suits <b>L59-022-R</b> Kit Contains: 2 x UB59-453-1	2	<b>UB59-453-1K</b>						
<b>SHOCK ABSORBER</b>									
	Twin Tube Gas Soft Option (Big Bore)	2	<b>GS45-115</b>			Twin Tube Gas Heavy Duty (Big Bore)	2	<b>GS59-079</b>	
	Twin Tube Gas Heavy Duty, Long Travel (Big Bore)	2	<b>GS59-703</b>			Monotube Remote Reservoir Heavy Duty	2	<b>MR45-60115</b>	
<b>SHACKLE</b>									
	Greasable: Fit in Pairs	2	<b>SK59-051</b>						
<b>PIN</b>									
	Greasable: Fit in Pairs	2	<b>SP59-044</b>						



**TYPE:** Landcruiser  
**MODEL:** 76 Series - FZJ76, HZJ76, VDJ76  
**YEAR:** 04/2007 on  
**DETAIL:** Station Wagon, V8 Turbo Diesel



FRONT			REAR														
QTY	PART NUMBER	PRICE	QTY	PART NUMBER	PRICE												
<b>CONTINUED FROM PREVIOUS PAGE</b>																	
<b>CASTOR KIT</b>																	
Raising Vehicle Will Effect Castor Angle. A Wheel Alignment is Recommended to Determine if a Castor Kit is Required.																	
<table border="0" style="width: 100%;"> <tr> <td style="width: 15%; color: red;">Adjustable</td> <td style="width: 65%;">Front Radius Arm Castor Kit <b>Angle Settings: ±0° or ±2.5°</b> 4 x Polyurethane Eccentric Bushes</td> <td style="width: 10%; text-align: center;">1</td> <td style="width: 10%;"><b>PB59-503K</b></td> <td style="width: 10%;"></td> <td style="width: 10%;"></td> </tr> <tr> <td style="color: red;">Fixed Rubber</td> <td>Front Radius Arm Castor Kit <b>Angle Setting: ±2.5°</b> 4 x Rubber Eccentric Bushes</td> <td style="text-align: center;">1</td> <td><b>RB59-522K</b></td> <td></td> <td></td> </tr> </table>						Adjustable	Front Radius Arm Castor Kit <b>Angle Settings: ±0° or ±2.5°</b> 4 x Polyurethane Eccentric Bushes	1	<b>PB59-503K</b>			Fixed Rubber	Front Radius Arm Castor Kit <b>Angle Setting: ±2.5°</b> 4 x Rubber Eccentric Bushes	1	<b>RB59-522K</b>		
Adjustable	Front Radius Arm Castor Kit <b>Angle Settings: ±0° or ±2.5°</b> 4 x Polyurethane Eccentric Bushes	1	<b>PB59-503K</b>														
Fixed Rubber	Front Radius Arm Castor Kit <b>Angle Setting: ±2.5°</b> 4 x Rubber Eccentric Bushes	1	<b>RB59-522K</b>														
<b>SWAY BAR EXTENSION</b>																	
<table border="0" style="width: 100%;"> <tr> <td style="width: 15%; color: red;">Adjustable</td> <td style="width: 65%;">Sway Bar Extension (Suits 2" to 4" Lift)</td> <td style="width: 10%; text-align: center;">1</td> <td style="width: 10%;"><b>WA59-543K</b></td> <td style="width: 10%;"></td> <td style="width: 10%;"></td> </tr> </table>						Adjustable	Sway Bar Extension (Suits 2" to 4" Lift)	1	<b>WA59-543K</b>								
Adjustable	Sway Bar Extension (Suits 2" to 4" Lift)	1	<b>WA59-543K</b>														
Must Be Fitted for Tail-Shaft/Swaybar Clearance																	
<b>ABS CABLE BRACKET KIT</b>																	
<table border="0" style="width: 100%;"> <tr> <td style="width: 15%;"></td> <td style="width: 65%;">ABS Cable Bracket Kit</td> <td style="width: 10%; text-align: center;">1</td> <td style="width: 10%;"><b>WA59-544K</b></td> <td style="width: 10%;"></td> <td style="width: 10%;"></td> </tr> </table>							ABS Cable Bracket Kit	1	<b>WA59-544K</b>								
	ABS Cable Bracket Kit	1	<b>WA59-544K</b>														
Must Be Fitted To Vehicles With ABS Brakes																	
<b>COIL SPACER</b>																	
<table border="0" style="width: 100%;"> <tr> <td style="width: 15%;"></td> <td style="width: 65%;">10mm</td> <td style="width: 10%; text-align: center;">2</td> <td style="width: 10%;"><b>PS21-4008</b></td> <td style="width: 10%;"></td> <td style="width: 10%;"></td> </tr> <tr> <td></td> <td>30mm</td> <td style="text-align: center;">2</td> <td><b>PS21-4009</b></td> <td></td> <td></td> </tr> </table>							10mm	2	<b>PS21-4008</b>				30mm	2	<b>PS21-4009</b>		
	10mm	2	<b>PS21-4008</b>														
	30mm	2	<b>PS21-4009</b>														